ESWT Transmitters for R-SW Handpiece »ultra«

STORZ MEDICAL

Standard Transmitters
Trigger Points/Enthesopathies

A6 »Point«

- Ø 6 mm, AkuSt transmitter
- Shock wave acupuncture, trigger points
- Penetration depth: 0 – 20 mm
- Intensity:

T10 »Finger«

- Ø 10 mm, trigger point transmitter
- Trigger points, deep target enthesopathies
- Penetration depth: 0 – 40 mm
- Intensity:

C15 »Ceramic Energy«

- Ø 15 mm, CERAma-x® transmitter
- Any type of enthesopathy
- Penetration depth: 0 – 30 mm
- Intensity:

R15 »Standard«

- Ø 15 mm, standard transmitter
- Any type of enthesopathy
- Penetration depth: 0 – 35 mm
- Intensity:

DI15 »Golden Depth«

- Ø 15 mm, Deep Impact® transmitter
- Deep target areas, chronic disorders, high-energy applications
- Penetration depth: 0 – 50 mm
- Intensity:

F15 »White Soft«

- Ø 15 mm, »Focus-Lens« transmitter
- Superficial pain regions, muscles of mastication, cervical spine
- Penetration depth: 0 – 30 mm
- Intensity:

Standard Transmitters
Myofascial Treatment

D20-S »Standard Oscillator«



- Ø 20 mm, D-ACTOR® transmitter
- Muscle and connective tissue
- Penetration depth: 0 – 50 mm
- Intensity:

D20-T »Golden Oscillator«



- Ø 20 mm, D-ACTOR® transmitter
- For professional athletes, high-energy applications
- Penetration depth: 0 – 50 mm
- Intensity:

D35-S »Large Oscillator«



- Ø 35 mm, D-ACTOR® transmitter
- Muscle and connective tissue, large muscles
- Penetration depth: 0 – 60 mm
- Intensity: